

DATE :

FLEET NO :

ODOMETER :

REGO :



# Adelaide Heavy Vehicles

## TRAILER SERVICE

A	B	C
X	X	X
X	X	X
X	X	X
X	X	X
X	X	X
X	X	X
X	X	X
X	X	X
X	X	X
X	X	X
		X
	X	X
		X
	X	X
	X	X
	X	X
	X	X
	X	X
	X	X
	X	X
	X	X
	X	X
	X	X
X	X	X

Legend : A, B, C - Service Level / Type		
1		Walk around Trailer & check for any obvious damage
2		Check Mudguards / Replace if require
3		Check all Mudflaps for damage / Replace if required
4		Check 7 Pin plugs / Replace if required
5		Check & ensure all Clearance lights are working
6		Check & ensure all indicators are working
7		Check & ensure all Brake lights are working
8		Check & ensure Rotating beacon is working
9		Check all Relfecors for damage / Replace if required
10		Check Safety Signs / Replace if damaged or faded
11		Check Number plate for damage
12		Check Registration label / Ensure current & readable
13		Check NHVAS label / Ensure is readable
14		Check Tyres for damage & condition
15		Check for cracks in Chassis structure / Suspension mounts / Axles
16		Check Shock absorbers for oil leaks & worn bushes
17		Check for broken Springs or Leaking airbags
18		Check all Suspension bushes for wear & security
19		Check Ride height & Adjust if required
20		Check Brake boosters for air leaks / Maxi & Service sides
21		Check Air system for leaks & Hoses for chafe points / Drain air tanks
22		Jack up Wheels & Check Wheel bearing adjustment / Adjust if required
23		Remove & inspect wheel bearings / Repack or replace if required
24		Check Ringfeder for correct operation & wear
25		Check operation of Wistlocks & Lubricate with CRC
26		Check operation of Extendable trailers
27		Check operation of Amps
28		Check Turntable & Adjust if required / Apply grease to top
29		Check & Adjust all Brakes

<b>X</b>	<b>X</b>	<b>X</b>	<b>30</b>	<b>Lubricate all grease points / including landing legs</b>
		<b>X</b>	<b>31</b>	<b>Check Dolly tow eye for wear / Replace if required</b>
	<b>X</b>	<b>X</b>	<b>32</b>	<b>Check Dolly draw bar pivot bolts for security ( Spot weld end of thread)</b>
	<b>X</b>	<b>X</b>	<b>33</b>	<b>Check Kingpin for wear / Check Bolt torque</b>
		<b>X</b>	<b>34</b>	<b>Check Skid plate for wear</b>
		<b>X</b>	<b>35</b>	<b>Check Landing leg operation</b>
<b>X</b>	<b>X</b>	<b>X</b>	<b>36</b>	<b>Update / Change Service sticker</b>
<b>X</b>	<b>X</b>	<b>X</b>	<b>37</b>	<b>Book out all parts &amp; Lubricants</b>
<b>X</b>	<b>X</b>	<b>X</b>	<b>38</b>	<b>Book out Hours worked</b>
<b>X</b>	<b>X</b>	<b>X</b>	<b>39</b>	<b>Perform Tug test when leaving workshop</b>